



Integrator 110

User Manual



MesaLabs

Mesa's Commitment

As a manufacturer of critical equipment, quality is the highest priority in our manufacturing process. Mesa commits to providing creative, innovative thinking and the engineering and scientific expertise needed to produce gas flow-related products and solutions that are universally recognized for their superior performance, quality and value.

Bios DryCal technology is the recognized leader in gas flow measurement, providing the industry's most reliable products, service and solutions for professionals in environmental protection, workplace safety, industrial process control and laboratory calibration.

We strive to provide the closest NIST-traceable, legal defensibility of any flow calibration equipment manufacturer, and we actively maintain our NVLAP (NIST) ISO 17025 laboratory accreditation in order to support our claims and continually improve our quality system and laboratory proficiency. Thank you for purchasing our products. From all of us at Mesa, best wishes for many years of accurate, defensible primary flow measurements.

Table of Contents

Introduction.....	2
Register Your Product	2
About Your Integrator 110	2
Operating Your Integrator 110.....	3
Getting Started.....	3
Features.....	3
Using Your Integrator 110.....	4
Connectivity Diagram	4
The Main Menu: Three Modes of Operation	5
Input & Output Signal Check – Diagnostics.....	5
MFC Control: Operation One.....	5
Compare MFC and ML: Operation Two.....	6
Compare MFM and ML: Operation Three.....	7
Maintenance and Troubleshooting	9
Annual Calibration.....	9
Sending Your Integrator 110 to Mesa	9
Troubleshooting.....	10
Shipping	10
Pin Configuration (25-pin D-Sub).....	11
Make MFC/MFM Cable	12
DB25 Pin Designation.....	13
Integrator 110 Specifications.....	13
Limited Warranty.....	14

-  Accuracy
-  Reliability
-  Convenience

Introduction

Congratulations! You've chosen the Mesa Integrator™ 110 command, control and readout device. This powerful tool integrates Proven Bios DryCal® Technology and a range of systems to make it easier than ever to perform in-house verifications and multi-setpoint calibrations of your analog mass flow devices.

Before you get started, we recommend taking a few moments to review this manual and familiarize yourself with your Integrator 110. If at any time you have questions regarding its operation, please contact Mesa through our Web site (<http://drycal.mesalabs.com>), or call us at 973.492.8400 to speak with one of our knowledgeable customer support representatives.

Register Your Product

Before we begin, please register your product with Mesa Laboratories, Inc. To complete your registration, log on to our website at <http://drycal.mesalabs.com> and complete the registration form. Registration of your new Bios DryCal product ensures your instruments warranty claim information is properly documented in Mesa's database, and provides you the peace of mind that your new calibration equipment is covered under our warranty service plan. Additionally, this registration will allow you to better manage your service and calibration dates through the receipt of timely reminders at 45 and 15 days prior to the recommended calibration date of your instrument.

Mesa recommends annual service and calibration of your Bios DryCal primary gas flow standard as a periodic quality assurance measure, as well as to provide you and your organization with a defensible audit trail of premier quality.

About Your Integrator 110

The Integrator 110 is a microprocessor-based, two-channel device that powers, controls and integrates analog mass flow controllers (MFC) and mass flow meters (MFM), enabling them to be verified and calibrated by the Mesa Met Lab® and Definer® Series of primary piston provers, which feature Proven Bios DryCal® Technology. Please note that these products are referred to within your Integrator's menu screens as "DryCal".

One of the Integrator's channels controls and monitors the gas flow through an MFC, the other channel monitors the flow through an MFM.

Your Integrator 110 comes with the following:

- Power Cord
- PC Serial Cable
- Calibration Certificate (voltage and current)
- Manual

The rear panel features the following ports and switches for integrating various components (from left to right):

POWER INPUT. An IEC-320 power connector for A/C power operation with an integral On/Off power switch.

PC. A 9-pin female D-sub connector. Connects your Integrator 110 to your PC.

DRYCAL. A 9-pin female D-sub connector. Connects your Integrator 110 to your Mesa Met Lab® Series primary piston prover.

AUX. An extra port that's currently not used, but may serve as an expansion port in the future.

MFM/EXPANSION PORT. A multi-function port. It's a 25-pin D-sub connector for attaching MFM cables (cables vary by MFM manufacturer; Mesa offers various cable types for your convenience). It may also be used to "warm up" a mass flow device while you're simultaneously calibrating another device via the MFC port. If and when Mesa enables the manipulation of additional devices, it will also serve as an expansion port.

MFC PORT. A 25-pin D-sub connector for attaching MFC cables (cables vary by MFC manufacturer; Mesa offers various cable types for your convenience).

VALVE. An extra port that's currently not used, but may serve as an expansion port in the future.

FAN. A 25mm x 8mm cooling fan (exhaust) with a finger guard for your protection.

RESET SWITCH. A "hard" reset that returns your Integrator 110 to the main menu. Your settings for the current calibration process will be lost.

PROGRAM LOAD SWITCH. Allows you to "flash" upgrade your Integrator 110's firmware in order to take advantage of available upgrades.


Using Your Integrator 110

Connectivity Diagram

Use Figure 3 to familiarize yourself with your Integrator 110's connectivity options.

Your Integrator 110 is equipped with three serial ports (RS-232). The PC port connects to your PC, the DryCal port to your Met Lab and Definer Series primary piston prover, and the AUX port is an expansion port for future use as available. Two D-25 (D-Sub) ports are available for use with MFCs and MFMs. The program load switch enables you to flash upgrade your Integrator 110.

Figure 3 – Connectivity Diagram



The Main Menu: Three Modes of Operation

Your Integrator 110's main menu offers three modes of operation:

Control MFC. Allows you to create an MFC setpoint and read the MFC's output signal.

Compare MFC and DryCal. With the MFC as the device under test, you can create an MFC setpoint, read the MFC's output signal and then compare the output signal to your DryCal's flow measurements. A deviation percentage is displayed on your Integrator 110's screen.

Compare MFM and DryCal. With the MFC as the flow source and the MFM as the device under test, you can create an MFC setpoint to generate a specific flow rate, read your MFM's output signal and then compare the output signal to your DryCal's flow measurements. A deviation percentage is displayed on your Integrator 110's screen.


Input & Output Signal Check – Diagnostics

As a quality assurance measure, your Integrator 110 has a diagnostics function that enables you to review the setpoint and/or output signals from your mass flow device. Within certain menu screens (such as MFC Output), Diagnostics may be accessed during any of the three modes of operation by navigating to the "Diag" option, located in the bottom-right corner of the screen.

The signal levels reflect the MFC's setpoint and output flow rates, or MFM's output flow rate.

Control MFC: Operation One


MFC Control describes the mode of operation for controlling an MFC using your Integrator 110.



1. Attach the appropriate MFC cable into the MFC and your Integrator 110.
2. Connect your gas supply to the MFC.
3. Turn on your Integrator 110.
4. Once the splash screen ends, select "Control MFC" and press ENTER.
5. At "Input to MFC" select the analog signal, then navigate to "Next" and press ENTER.
6. At "Output from MFC" select the analog signal, then navigate to "Next" and press ENTER.
7. At "Connect MFC" select "Next" and press ENTER to begin "Checking Setup." Your Integrator 110 will check the MFC's connection.
8. Gas flow needs to be turned on for a successful connection, select "continue" to ignore this step.
9. Upon successful setup, input the "MFC Full Scale Flow" value (the rated flow of the MFC) using the keypad, and press ENTER. Then, arrow down to select the flow units using the right and left arrows, then navigate to "Next" and press ENTER.
10. Input the "MFC Setpoint" (within the rated specification of the MFC) using the keypad, and press ENTER. Then, navigate to "Next" and press ENTER.
11. When the display begins flashing, your Integrator 110 is updating the MFC's output reading against the MFC's setpoint value.
12. To change the MFC's flow, navigate to BACK and press ENTER. Input the new "MFC Setpoint" and follow Steps 9 through 10 as prompted.

Compare MFC and DryCal: Operation Two

Compare MFC and DryCal describes the mode of operation for comparing an MFC to your Met Lab primary piston prover using your Integrator 110.




1. Attach the appropriate MFC cable into the MFC and your Integrator 110.
2. Attach the 9-pin cable into your DryCal and your Integrator 110.
3. Connect your gas supply to the MFC, connect the outlet of the MFC to the inlet of the DryCal.
4. Turn on your Integrator 110 and your DryCal. Make sure that your DryCal is set to read in sccm and the temperature correction matches that of the MFC under test.
5. Once the splash screen ends, select "Compare MFC and DryCal" and press ENTER.
6. At "Input to MFC" select the analog signal, then navigate to "Next" and press ENTER.
7. At "Output from MFC" select the analog signal, then navigate to "Next" and press ENTER.
8. At "Connect MFC and DryCal" select "Next" and press ENTER to begin "Checking Setup." Your Integrator 110 will check the communication among all systems.
9. Gas flow needs to be turned on for a successful connection, select "continue" to ignore this step.
10. Upon successful setup, at "% Deviation" select the deviation type, then navigate to "Next" and press ENTER.
11. At "MFC Full Scale Flow" (the rated flow of the MFC) input the value using the keypad, and press ENTER. Then, arrow down to select the flow units using the right and left arrows, then navigate to "Next" and press ENTER.
12. Input the "MFC Setpoint" (within the rated specification of the MFC) using the keypad, and press ENTER. Then, navigate to "Next" and press ENTER.
13. When the display begins flashing, your Integrator 110 is updating the MFC's output reading against the MFC's setpoint value, and the DryCal's flow measurement is recorded and updated. The deviation percentage between MFC and the DryCal is displayed.
14. To change the MFC's flow, navigate to BACK and press ENTER. Input the new "MFC Setpoint" and follow Steps 11 through 12 as prompted.

Compare MFM and DryCal: Operation Three


Compare MFM and DryCal describes the mode of operation for controlling flow through an MFM via an MFC or via an external device (i.e., needle valve, sonic nozzle) using your Integrator 110.

Via an MFC



1. Attach the appropriate MFC cable into the MFC and your Integrator 110.
2. Attach the appropriate MFM cable into the MFM and your Integrator 110.
3. Attach the 9-pin cable into your DryCal and your Integrator 110.
4. Connect your gas supply to the MFC, connect the outlet of the MFC to the inlet of the MFM, connect the outlet of the MFM to the inlet of the DryCal.
5. Turn on your Integrator 110 and your DryCal. Make sure that your DryCal is set to read in sccm and the temperature correction matches that of the MFC under test.
6. Once the splash screen ends, select "Compare MFM and DryCal" and press ENTER.
7. At "MFM Output Signal" select the analog signal, then navigate to "Next" and press ENTER.
8. At "MFM Flow Source" select "MFC" and press ENTER.
9. At "Input to MFC" select the analog signal, then navigate to "Next" and press ENTER.
10. At "Output from MFC" select the analog signal, then navigate to "Next" and press ENTER.
11. At "Connect MFC and MFM and DryCal" select "Next" and press ENTER to begin "Checking Setup." Your Integrator 110 will check the communication among all systems.
12. Gas flow needs to be turned on for a successful connection, select "continue" to ignore this step.
13. Upon successful setup, at "% Deviation" select the deviation type, then navigate to "Next" and press ENTER.
14. At "MFM Full Scale Flow" (the rated flow of the MFM) input the value using the keypad, and press ENTER. Then, arrow down to select the flow units using the right and left arrows, then navigate to "Next" and press ENTER.
15. At "MFC Full Scale Flow" (the rated flow of the MFC) input the value using the keypad, and press ENTER. Then, arrow down to select the flow units using the right and left arrows, then navigate to "Next" and press ENTER.
16. Input the "MFC Setpoint" (within the rated specification of the MFC) using the keypad, and press ENTER. Then, navigate to "Next" and press ENTER.
17. When the display begins flashing, your Integrator 110 is updating the MFM's output reading against the MFC's setpoint, and the DryCal's flow measurement is recorded and updated. The deviation percentage between MFM and the DryCal is displayed.
18. Press 'back' to change the flow to the MFM and repeat Steps 15 through 16 as prompted.

Via an External Device



1. Attach the appropriate MFM cable into the MFM and your Integrator 110.
2. Attach the 9-pin cable into your DryCal and your Integrator 110.
3. Connect your gas supply to the external mechanical device, connect the outlet of the external mechanical device to the inlet of the MFM, connect the outlet of the MFM to the inlet of the DryCal.
4. Turn on your Integrator 110 and your DryCal. Make sure that your DryCal is set to read in sccm and the temperature correction matches that of the MFC under test.
5. Once the splash screen ends, select "Compare MFM and ML" and press ENTER.
6. At "MFM Output Signal" select the analog signal, then navigate to "Next" and press ENTER.
7. At "MFM Flow Source" select "EXT Mechanical" and press ENTER.
8. At "Connect MFM and DryCal" select "Next" and press ENTER to begin "Checking Setup." Your Integrator 110 will check the communication among all systems.
9. Gas flow needs to be turned on for a successful connection, select "continue" to ignore this step.
10. Upon successful setup, at "% Deviation" select the deviation type, then navigate to "Next" and press ENTER.
11. At "MFM Full Scale Flow" (the rated flow of the MFM) input the value using the keypad, and press ENTER. Then, arrow down to select the flow units using the right and left arrows, then navigate to "Next" and press ENTER.
12. The flow indicated by the DryCal unit is recorded and updated in this step with a percentage deviation between MFM and DryCal readings.

Maintenance and Troubleshooting

Annual Calibration

Your Integrator 110 is a high precision voltage and current measuring device that is used to provide set points and read voltage and current signals from mass flow devices. As such, your Integrator 110's voltage and current settings should be calibrated at least annually by an ISO 17025-accredited calibration laboratory, such as Mesa's Butler, NJ site.

Please note that while any ISO 17025-accredited gas flow measurement laboratory may be capable of calibrating your Integrator 110, Mesa is the only authorized service center for Bios DryCal products. All Integrator 110 service and calibration is performed in our ISO 17025-accredited laboratory in New Jersey by experienced personnel.

Turnaround time within Mesa's facility is generally two weeks. For an expedite fee and as available, we will place your Integrator 110 "next on bench" for 48-hour turnaround. This means that an Integrator 110 received on Monday will be return-shipped on Wednesday and a Integrator 110 received on Friday will be return-shipped on Tuesday. Although we cannot guarantee successful expedited turnaround, we will make every effort to accommodate your request.

For a detailed explanation of our service process, expedite option and to obtain current calibration pricing, please contact us at 973.492.8400 or visit our web site at <http://drycal.mesalabs.com>.

Sending Your Integrator 110 to Mesa

Please contact Mesa for an RMA (return merchandise authorization) number before sending your Integrator 110 to our factory for annual calibration or other service. You can get an RMA number through our automated web-based system at <http://drycal.mesalabs.com>, by email to biosdrycal@mesalabs.com, or by telephone at 973.492.8400.

Sending your Integrator 110 to Mesa without an RMA number may result in return of the instrument without inspection or a substantial delay in service turnaround time.

When requesting your RMA number, provide your Integrator 110 serial number and revision level, as well as your full contact information. Also, please describe any product issues you may be experiencing. Please keep in mind that Mesa will not begin evaluation and service of your Integrator 110 until you have accepted and approved, in writing, our formal RMA quote for service. This protects both you and Mesa during this process and ensures a fair and efficient service experience.

If sending your Integrator 110 for warranty evaluation or repair, please contact Mesa for troubleshooting assistance prior to shipment to our facility (see Troubleshooting).

Troubleshooting

If you should encounter any problems with your Integrator 110, please contact Mesa Customer Service and provide a detailed description of your situation, including your Integrator 110 serial number, information about the flow source, the current calibration setup, environmental conditions during the test, the flow point or points that you're checking and an explanation of the issue you're experiencing.

With your help, our technical support team will attempt to resolve the situation over the phone and/or via email. If we're unable to do so, we'll issue you an RMA number for the prompt return of your Integrator 110 for evaluation.

Before contacting Mesa with any problems, please verify the following:

- Is your Integrator 110 plugged into the appropriate power source and turned on?
- Are all of the appropriate cables plugged into the devices under test?
- Are all of the appropriate cables plugged into your Integrator 110?
- Are you using the correct setups (voltage and/or current) for devices you're operating?
- Is your DryCal Series primary piston prover powered on?
- Are your DryCal settings correct? For example, standardized flow, standardizing temperature, Sensor Factors, etc.
- Is your gas supply on?
- Are all the pneumatic connections correct and tight?

Mesa will make every attempt to verify your issue, as we want you to get the most out of your Integrator 110. However, if you've shipped your Integrator 110 to Mesa for an issue that we're unable to verify – or, if we determine that the issue is application-related rather than product-related – we reserve the right to charge an evaluation fee at prevailing labor rates.

Shipping

When shipping your Integrator 110, please ensure that the packaging is adequate to protect the instrument. Whenever possible, your Integrator 110 should be shipped in its original packaging or within a hard case, such as a Pelican carrying case (available for purchase from Mesa). We highly recommend using a standard freight carrier (e.g., FedEx, UPS) that supplies tracking numbers and insuring the product against damage in transit.

Mesa is generally not responsible for freight cost associated with shipments to and from Mesa, except in certain instances; please contact Mesa for information before initiating a shipment.

Mesa is not responsible for damage that occurs during shipment.

Pin Configuration (25-pin D-Sub)

Below is a table for the pin assignments for the MFC and MFM.

(Connector is on the back of the Integrator. Customers may use this to fabricate cables to connect to their MFC/MFMs or may purchase cables from Mesa Labs)

Pin No.	Description
1	Power Ground
2	N/C
3	Signal Ground
4	+ 15V_1.7A, MFC /MFM Power
5	GND2
6	N/C
7	N/C
8	N/C
9	N/C
10	N/C
11	N/C
12	Signal Voltage in MFC/MFM
13	N/C
14	N/C
15	Signal Voltage out MFC
16	N/C
17	N/C
18	Signal Current out MFC
19	N/C
20	N/C
21	N/C
22	Signal Current in MFC/MFM
23	-15V_1.7A, MFC/MFM Power
24	N/C
25	N/C

N/C = no connection

MFC/MFM Power Connections

A. + 15 VDC Supply Voltage

- Positive, pin 4
- Negative, pin 1

B. – 15 VDC Supply Voltage


- Negative, pin 23
- Positive, pin 1 (jumper pin 1 to pin 5)

C. 30 VDC Supply Voltage

- Positive, Pin 5 (jumper pin 4 to pin 23)
- Negative, pin 1

Drawing of MFC/MFM Connector on back of Integrator

25-pin D-Sub
(Female on Integrator 110)




Make a MFC/MFM Cable

Two MFC/MFM cables are supplied to a user with an Integrator 110.

The Integrator 110 side of the cable is connected to a fixed female DB25 pin.

The MFC/MFM side of the cable is left open-ended for the users to configure and connect to their MFC/MFM connector. This side can be connected to a DB15, DB9, DB25 etc based on the type of MFC/MFM pin connector. There are a total of nine terminals brought out for the users to configure their own cable.

Figure 4 – MFC/MFM Cable



DB25 Pin Designation

Configure your MFC/MFM cable as the connection table below.

Pin No.	Description	Wire Color
1	Power Ground	Black
2	N/C	
3	Signal Ground	White
4	+ 15V_1.7A, MFC /MFM Power	Red
5	GND2	Brown
6	N/C	
7	N/C	
8	N/C	
9	N/C	
10	N/C	
11	N/C	
12	Signal Voltage from MFC/MFM	Yellow
13	N/C	
14	N/C	
15	Signal Voltage to MFC	Orange
16	N/C	
17	N/C	
18	Signal Current to MFC	Green
19	N/C	
20	N/C	
21	N/C	
22	Signal Current from MFC/MFM	Blue
23	-15V_1.7A, MFC/MFM Power	Purple
24	N/C	
25	N/C	

N/C = no connection

Integrator 110 Specifications

Input	
Power:	90-264 VAC, 47-53 Hz.
Operating Temperature:	0-50°C
Storage Temperature:	-20 - 85°C
Communication Ports:	9-pin D-Sub (RS232)
MFC Electrical Connection:	25-pin D-Sub
MFM Electrical Connection:	25-pin D-Sub
Optional Valve Electrical Connection:	9-pin D-Sub
MFC/MFM:	4-20 ma, 0-20 ma, 1-5 V or 0-5 V

Special Notes:

A. + 15 VDC Supply Voltage

- Positive/+15 V, pin 4
- Negative/ Power ground, pin 1

B. – 15 VDC Supply Voltage

- Negative/-15 V, pin 23
- Positive/ Power ground, pin 1 (jumper pin 1 to pin 5)

C. 30 VDC Supply Voltage

- Positive/30 V, Pin 5 (jumper pin 4 to pin 23)
- Negative, pin 1

The jumpers for – 15 V/ 30 V are not connected at the Integrator side. Make connection at the MFC/MFM side

D. Signal Voltage from MFC/MFM and Signal Voltage to MFC are 0-5 VDC or 1-5 VDC

E. Signal Current from MFC/MFM and Signal Current to MFC are 0–20 milliAmp DC or 4-20 milliAmp DC

Output	
Power Supply:	+/- 15 VDC or 30 VDC
Current:	4-20 ma, 0-20 ma
Resolution:	0.4 micro-amp
Uncertainty:	.015% Full Scale
Voltage:	1-5 V, 0-5 V
Resolution:	0.1 mVDC
Uncertainty:	.015% FS

Limited Warranty

The Mesa Integrator 110 is warranted to the original end user to be free from defects in materials and workmanship under normal use and service for a period of one year from the date of purchase as shown on the purchaser's receipt. If your Integrator 110 was purchased from an authorized reseller, a copy of an invoice or packing slip showing the date of purchase may be required to obtain warranty service.

The obligation of Mesa Laboratories, Inc. under this warranty shall be limited to repair or replacement (at our option), during the warranty period, of any part that proves defective in material or workmanship under normal use and service, provided the product is returned to Mesa Laboratories, Inc., transportation charges prepaid.

Notwithstanding the foregoing, Mesa Laboratories, Inc. shall have no liability to repair or replace any Mesa Laboratories, Inc. product:

1. That has been damaged following sale, including but not limited to damage resulting from improper electrical voltages or currents, defacement, misuse, abuse, neglect, accident, fire, flood, terrorism, act of God or use in violation of the instructions furnished by Mesa Laboratories, Inc.;
2. When the serial number has been altered or removed; or,
3. That has been repaired, altered or maintained by any person or party other than Mesa Labs' own service facility or a Mesa authorized service center, should one be established.

This warranty is in lieu of all other warranties, and all other obligations or liabilities arising as a result of any defect or deficiency of the product, whether in contract or in tort or otherwise. All other warranties, expressed or implied, including any implied warranties of merchantability and fitness for a particular purpose, are specifically excluded.

In no event shall Mesa be liable for any special, incidental or consequential damages for breach of this or any other warranty, express or implied, whatsoever.



Mesa Labs

10 Park Place
Butler, NJ, USA 07405

Phone: 973.492.8400
Toll Free: 800.663.4977
Fax: 973.492.8270

Email: biosdrycal@mesalabs.com
web: www.mesalabs.com